

# Alphabetical index

## Alphabetical index

### A

#### A/C

Air conditioning filter .....	471
Front air conditioning system .....	341
Rear air conditioning system .....	355

#### ABS.....308

#### ACCESSORY mode .....185

#### Adaptive front-lighting system..... 218

#### Advanced parking guidance system.....267

#### AFS .....218

#### Air conditioning filter .....471

#### Air conditioning system

Air conditioning filter .....	471
Front air conditioning system .....	341
Rear air conditioning system .....	355

#### Airbags

Airbag operating conditions.....	144
Airbag precautions for your child.....	148
Airbag warning light .....	505
Curtain shield airbag operating conditions.....	145
Curtain shield airbag precautions .....	148
Front passenger occupant classification system.....	153

#### General airbag precautions.....148

#### Locations of airbags.....140

#### Modification and disposal of airbags.....152

#### Proper driving posture.....138, 148

#### Side airbag operating conditions.....145

#### Side airbag precautions.....148

#### SRS airbags.....140

#### Alarm.....135

#### Anti-lock brake system.....308

#### Armrest .....395

#### Ashtrays.....383

#### Audio system\*

#### Automatic air conditioning system

Air conditioning filter .....	471
Front air conditioning system.....	341
Rear air conditioning system.....	355

#### Automatic headlight leveling

#### system .....219

#### Automatic high beam .....220

#### Automatic light control system.....216

#### AUX port\*

#### Auxiliary box

Auxiliary box.....	377
Non smokers box.....	376

#### A/V input port\*

<b>B</b>	<b>Back-up lights</b>	
	Replacing light bulbs .....	484
	Wattage .....	558
	<b>Battery</b>	
	Checking .....	452
	Hybrid battery	
	(traction battery) .....	40
	If the vehicle has a discharged	
	12-volt battery .....	535
	Preparing and checking before	
	winter .....	331
	<b>Bluetooth®*</b>	
	<b>Brakes</b>	
	Brake hold .....	199
	Fluid .....	450
	Parking brake .....	196
	<b>Brake assist</b> .....	308
	<b>Brake hold</b> .....	199
	<b>Break-in tips</b> .....	175

<b>C</b>	<b>Care</b>	
	Exterior .....	422
	Interior .....	425
	Seat belts .....	426
	<b>Cargo capacity</b> .....	326
	<b>Cargo hooks</b> .....	406
	<b>CD player/changer*</b>	
	<b>Chains</b> .....	332
	<b>Child restraint system</b>	
	Booster seats, definition .....	158
	Booster seats, installation .....	163
	Convertible seats, definition .....	158
	Convertible seats, installation .....	163
	Front passenger occupant	
	classification system .....	153
	Infant seats, definition .....	158
	Infant seats, installation .....	163
	Installing CRS with LATCH	
	system .....	164
	Installing CRS with seat belts .....	166
	Installing CRS with top tether	
	straps .....	169

\*: Refer to the "Navigation System Owner's Manual"

<b>Child safety</b>	
Airbag precautions.....	148
Child restraint system.....	158
Child-protectors.....	71
Heated steering wheel	
precautions .....	390
How your child should wear the	
seat belt .....	112
Installing child restraints .....	163
Moon roof precautions .....	124
Power window lock switch.....	121
Power window precautions .....	123
Removed electronic key battery	
precautions .....	475
Seat belt comfort guide.....	110
Seat belt extender precautions .....	115
Seat belt precautions .....	113
Seat heater precautions .....	394
Trunk precautions.....	78
12-volt battery	
precautions .....	454, 537
<b>Child-protectors</b> .....	71
<b>Cigarette lighter</b> .....	384
<b>Cleaning</b>	
Exterior .....	422
Interior.....	425
Seat belts.....	426
<b>Climate control seat</b> .....	391
<b>Climate control seat filter</b> .....	473
<b>Clock*</b>	
<b>Coat hooks</b> .....	404
<b>Coin holder</b> .....	372

## D

<b>Condenser</b> .....	449
<b>Console box</b> .....	374
<b>Cooling system</b>	
Hybrid system overheating.....	539
<b>Cornering assist sensors</b> .....	250
<b>Cruise control</b>	
Cruise control.....	233
Dynamic radar cruise	
control .....	237
<b>Cup holders</b> .....	373
<b>Curtain shield airbags</b> .....	140
<b>Customizable features</b> .....	573
<b>Daytime running light system</b> .....	218
<b>Defogger</b>	
Rear window .....	363
Side mirrors.....	363
<b>Dimensions</b> .....	546
<b>Dinghy towing</b> .....	336
<b>Display</b>	
Dynamic radar cruise control.....	237
Energy flow .....	41
Multi-information display .....	211
Touch screen .....	338
Trip information.....	212
Warning message.....	514
<b>Do-it-yourself maintenance</b> .....	434
<b>Door courtesy lights</b>	
Door courtesy lights.....	365
Wattage .....	558
<b>Door pockets</b> .....	372

**Doors**

- Door lock .....54, 67, 70
- Door windows.....121
- Side mirrors.....119

**Driver's seat belt reminder light .... 508**

**Driving**

- Break-in tips.....175
- Correct posture.....138
- Procedures.....174
- Winter driving tips .....331

**Driving position memory ..... 98**

**DVD player\***

**E Eco drive mode..... 191**

**Electric power steering ..... 308**

**Electronic key**

- If the electronic key does not  
operate properly.....531

**Electronically modulated air**

- suspension ..... 265

**Emergency flashers**

- Switch.....496

**Emergency, in case of**

- If a warning buzzer  
sounds .....504
- If a warning light turns on.....504
- If a warning message is  
displayed.....514
- If the electronic key does not  
operate properly.....531
- If the hybrid system will not  
start.....526

- If the parking brake cannot be  
released.....529

- If the shift lever cannot be shifted  
from "P" ..... 528

- If the vehicle has a discharged  
12-volt battery..... 535

- If you have a flat tire .....517

- If you lose your keys ..... 52

- If you think something is  
wrong ..... 503

- If your vehicle becomes  
stuck.....543

- If your vehicle has to be stopped  
in an emergency .....544

- If your vehicle needs to be  
towed.....497

- If your vehicle overheats ..... 539

**Engine**

- Accessory mode.....185

- Compartment..... 440

- Engine switch.....184

- Hood.....437

- How to start the hybrid  
system .....184

- Identification number .....547

- If the hybrid system will not  
start.....526

- Ignition switch .....184

- Overheating ..... 539

- Power switch.....184

\*: Refer to the "Navigation System Owner's Manual"

Engine compartment cover ..... 441

Engine coolant temperature  
gauge ..... 202

Engine/power control unit coolant  
Capacity ..... 551  
Checking ..... 447  
Preparing and checking before  
winter ..... 331

Engine oil  
Capacity ..... 549  
Checking ..... 443  
Preparing and checking before  
winter ..... 331

Engine switch ..... 184

EPS ..... 308

EV drive mode switch ..... 188

Event data recorder ..... 30

**F**

First-aid kit storage belt ..... 406

Floor mat ..... 405

Fluid  
Brake ..... 450  
Washer ..... 451

Fog lights  
Replacing light bulbs ..... 484  
Switch ..... 226  
Wattage ..... 558

Footwell lighting ..... 365

Front fog lights  
Replacing light bulbs ..... 484  
Switch ..... 226  
Wattage ..... 558

Front passenger occupant  
classification system ..... 153

Front passenger's seat belt  
reminder light ..... 508

Front seats  
Adjustment ..... 82  
Driving position memory ..... 98  
Power easy access system ..... 101  
Seat position memory ..... 98

Front turn signal lights  
Replacing light bulbs ..... 484  
Wattage ..... 558

Fuel  
Capacity ..... 548  
Fuel gauge ..... 202  
Information ..... 559  
Refueling ..... 128  
Type ..... 548

Fuel door ..... 128

Fuel filler door ..... 128

Fuses ..... 476

**G**

Garage door opener ..... 408

Gauges ..... 202

Glove box ..... 371

<b>H</b>	<b>Hazard lights</b>	
	Switch.....	496
	<b>Head restraints</b>	
	Active head restraint.....	106
	Adjustment .....	106
	<b>Headlight aim .....</b>	<b>482</b>
	<b>Headlight cleaner .....</b>	<b>232</b>
	<b>Headlights</b>	
	Automatic high beam .....	220
	Replacing light bulbs .....	484
	Switch.....	216
	Wattage .....	558
	<b>Heaters</b>	
	Seat heaters.....	391
	Side mirrors.....	363
	Steering wheel.....	389
	<b>Height control</b>	
	Electronically modulated air suspension.....	265
	<b>Hill-start assist control .....</b>	<b>308</b>
	<b>Hood .....</b>	<b>437</b>
	<b>Hooks</b>	
	Cargo.....	406
	Coat.....	404
	Shopping bag.....	406
	<b>Horn.....</b>	<b>201</b>

<b>Hybrid system</b>	
Emergency shut off system.....	41
Energy monitor/consumption screen.....	41
High voltage components .....	40
Hybrid system indicator .....	202
Power switch.....	184

<b>I</b>	<b>I/M test.....</b>	<b>433</b>
	<b>Identification</b>	
	Electric motor .....	547
	Engine.....	547
	Vehicle .....	547
	<b>Ignition switch.....</b>	<b>184</b>
	<b>Illuminated entry system .....</b>	<b>365</b>
	<b>Immobilizer system .....</b>	<b>133</b>
	<b>Indicator lights.....</b>	<b>207</b>
	<b>Inside rear view mirror .....</b>	<b>117</b>
	<b>Interior lights</b>	
	Switch.....	366
	Wattage.....	558

<b>J</b>	<b>Jack</b>	
	Positioning a floor jack.....	438
	Vehicle-equipped jack .....	517
	<b>Jack handle.....</b>	<b>517</b>

**K** Keyless entry..... 67

Keys

- Electronic key..... 49
- Engine switch..... 184
- If the electronic key does not  
operate properly .....531
- If you lose your keys..... 52
- Ignition switch..... 184
- Key number ..... 49
- Keyless entry ..... 67
- Keys ..... 49
- Mechanical key..... 49
- Power switch ..... 184
- Wireless remote control key ..... 67

**L** Lane-keeping assist..... 258

Lexus enform\*

Light bulbs

- Replacing ..... 484
- Wattage ..... 558

Lights

- Door courtesy lights..... 365
- Emergency flasher switch..... 496
- Fog light switch ..... 226
- Hazard light switch ..... 496
- Headlight switch..... 216
- Interior light switch ..... 366
- Outer foot lights..... 365
- Overhead courtesy light ..... 365
- Personal light switch..... 367
- Replacing light bulbs ..... 484
- Shift lever lighting ..... 365
- Turn signal lever..... 195
- Vanity lights..... 381
- Wattage ..... 558

LKA ..... 258

Load capacity..... 329

<b>M</b>	<b>Maintenance</b>	
	Do-it-yourself maintenance.....	434
	General maintenance.....	430
	Maintenance data .....	546
	Maintenance requirements.....	428
	<b>Maintenance data.....</b>	<b>429</b>
	<b>Meter</b>	
	Instrument panel light control.....	204
	Meters.....	202
	<b>Micro dust and pollen</b>	
	filter.....	349
	<b>Mirrors</b>	
	Inside rear view mirror .....	117
	Side mirror heaters.....	363
	Side mirrors.....	119
	Vanity mirrors .....	381
	<b>Moon roof.....</b>	<b>124</b>
	<b>Multi-information display.....</b>	<b>211</b>
<b>N</b>	<b>Noise from under vehicle.....</b>	<b>28</b>
<b>O</b>	<b>Odometer.....</b>	<b>202</b>
	<b>Oil</b>	
	Engine oil.....	443
	<b>Opener</b>	
	Fuel filler door .....	128
	Hood.....	437
	Trunk.....	75
	<b>Outer foot lights</b>	
	Outer foot lights.....	365
	Wattage .....	558

	<b>Outside rear view mirrors</b>	
	Adjusting and folding.....	119
	Mirror position memory.....	98
	<b>Outside temperature</b>	
	display .....	202, 382
	<b>Overhead console.....</b>	<b>377</b>
	<b>Overhead courtesy lights</b>	
	Overhead courtesy lights.....	365
	Wattage.....	558
	<b>Overheating, Hybrid system .....</b>	<b>539</b>
<b>P</b>	<b>Parking assist sensors .....</b>	<b>250</b>
	<b>Parking brake.....</b>	<b>196</b>
	<b>Parking lights</b>	
	Switch.....	216
	<b>PCS .....</b>	<b>315</b>
	<b>Pelvic support seat.....</b>	<b>93</b>
	<b>Penlight .....</b>	<b>518</b>
	<b>Personal lights</b>	
	Switch.....	367
	Wattage.....	558
	<b>Power outlets .....</b>	<b>386</b>
	<b>Power easy access system .....</b>	<b>101</b>
	<b>Power switch .....</b>	<b>184</b>
	<b>Power windows .....</b>	<b>121</b>
	<b>Pre-collision system.....</b>	<b>315</b>

\*: Refer to the "Navigation System Owner's Manual"



<b>R</b>	Radar cruise control.....	237
	Radiator .....	449
	Rear seat	
	Adjustment.....	88
	Seat position memory .....	104
	Rear seat entertainment system*	
	Rear seat relaxation system .....	94
	Rear sunshade .....	398
	Rear turn signal lights	
	Replacing light bulbs.....	484
	Wattage.....	558
	Rear window defogger.....	363
	Replacing	
	Electronic key battery.....	474
	Fuses .....	476
	Light bulbs.....	484
	Tires.....	517
	Reporting safety defects for U.S. owners.....	584
	Retractable table.....	396

<b>S</b>	Safety connect .....	414
	Seat belts	
	Adjusting the seat belt.....	110
	Automatic locking retractor.....	111
	Child restraint system	
	installation .....	158
	Cleaning and maintaining	
	the seat belts.....	426
	Emergency locking retractor .....	111
	How to wear your seat belt.....	109

	How your child should wear the seat belt.....	112
	Pregnant women, proper seat belt use.....	111
	Reminder light.....	508
	Seat belt extenders.....	112
	Seat belt pretensioners .....	110
	Seat cushion airbag .....	140
	Seat heaters .....	391
	Seat position memory.....	98, 104
	Seating capacity.....	329
	Seats	
	Adjustment .....	82, 88
	Adjustment	
	precautions .....	86, 96
	Child seat/child restraint system	
	installation .....	158
	Cleaning .....	425
	Climate control .....	391
	Climate control seat .....	391
	Driver's seat position memory .....	98
	Front passenger's seat	
	position memory.....	98
	Head restraint .....	106
	Pelvic support seat .....	93
	Power easy access system .....	101
	Properly sitting in the seat.....	138
	Rear seat position memory.....	104
	Rear seat relaxation system.....	94
	Seat heaters .....	391
	Seat position memory.....	98, 104

Service reminder indicators .....	207
Shift lever	
If the shift lever cannot be shifted from "P" .....	528
Transmission .....	190
Shift lever lighting .....	365
Shift lock system .....	528
Shopping bag hooks .....	406
Side airbags .....	140
Side marker lights	
Switch .....	216
Side mirrors	
Adjusting and folding .....	119
Mirror position memory .....	98
Smart access system with push-button start	
Entry function .....	54
Starting the hybrid system .....	184
"SOS" button .....	414
Spare tire	
Inflation pressure .....	465
Storage location .....	517
Spark plug .....	552
Specifications .....	546
Speedometer .....	202
Steering wheel	
Adjustment .....	116
Heated steering wheel .....	389
Lock release .....	186
Steering wheel position memory .....	98
Storage feature .....	369

## Stuck vehicle

If your vehicle becomes stuck .....	543
-------------------------------------	-----

## Sun visors .....

## Sunshades

Rear .....	398
Rear door .....	401
Roof .....	125

## Switch

APGS pre-support switch .....	269
Automatic high beam .....	220
Driving mode selector switch .....	191
"ECO MODE" switch .....	191
Emergency flasher switch .....	496
Engine switch .....	184
EV drive mode switch .....	188
Fog light switch .....	226
Hazard light switch .....	496
Heated steering wheel switch .....	389
Ignition switch .....	184
Light switches .....	216
Parking brake switch .....	196
Power door lock switch .....	70
Power switch .....	184
Power trunk opener and closer .....	75
Power window switch .....	121
Window lock switch .....	121
Wiper and washer switch .....	228

<b>T</b>	Tachometer.....	202
	Tail lights	
	Switch .....	216
	Talk switch .....	343
	Telephone switch*	
	Theft deterrent system	
	Alarm .....	135
	Immobilizer system.....	133
	Tire inflation pressure .....	465
	Tire information	
	Glossary.....	567
	Size .....	564
	Tire identification number .....	563
	Uniform tire quality grading .....	565
	Tires	
	Chains .....	332
	Checking .....	456
	If you have a flat tire.....	517
	Inflation pressure.....	465
	Information.....	562
	Replacing.....	517
	Rotating tires .....	456
	Size .....	556
	Snow tires.....	331
	Spare tire.....	517
	Tire pressure warning system .....	456
	Tools.....	517
	Total load capacity .....	329
	Touch screen.....	338

Towing	
Dinghy towing .....	336
Emergency towing.....	497
Trailer towing .....	335
TRAC .....	308
Traction control.....	308
Transmission	
If the shift lever cannot be shifted from "P" .....	528
"S" mode.....	192
Transmission.....	190
Trip meter .....	202
Trunk	
Closer .....	75
Opener .....	75
Trunk light	
Wattage .....	558
Turn signal lights	
Replacing light bulbs.....	484
Switch.....	195
Wattage .....	558
<b>V</b>	
Vanity lights	
Vanity lights.....	381
Wattage .....	558
Vanity mirrors.....	381
Variable gear ratio steering.....	308
VDIM.....	308
Vehicle dynamics integrated management .....	308
Vehicle identification number .....	547
Vehicle stability control .....	308
VGRS.....	308
VSC .....	308

**W**

**Warning buzzers**

Master warning .....	508
Open door .....	508
Seat belt reminder .....	508

**Warning lights**

Anti-lock brake system .....	505
Brake assist system .....	505
Brake system .....	504, 505
Charging system .....	504
Electric power steering .....	505
High coolant temperature .....	508
Low fuel level .....	508
Malfunction indicator lamp .....	505
Master warning .....	508
Open door .....	508
Pre-collision system .....	505
Pretensioners .....	505
Seat belt reminder .....	508
Slip indicator .....	505
SRS airbags .....	505
Tire pressure .....	508

**Warning messages.....514**

**Washer**

Checking .....	451
Preparing and checking before winter .....	331
Switch .....	228

**Washing and waxing.....422**

**Weight**

Cargo capacity .....	326
Load limits .....	329
Weight .....	546

**Wheels .....469**

**Window lock switch.....121**

**Windows**

Power windows .....	121
Rear window defogger .....	363
Washer .....	228

**Windshield wiper de-icer.....364**

**Windshield wipers.....228**

**Wireless remote control key**

Replacing the battery .....	474
Wireless remote control .....	67